

SUPER  [®]

X9 SMM IPMI

User's Guide

Revision 1.0

The information in this User's Manual has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, makes no commitment to update or to keep current the information in this manual, or to notify any person or organization of the updates. **Please Note: For the most up-to-date version of this manual, please see our web site at www.supermicro.com.**

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software and documentation, is the property of Supermicro and/or its licensors, and is supplied only under a license. Any use or reproduction of this product is not allowed, except as expressly permitted by the terms of said license.

IN NO EVENT WILL SUPER MICRO COMPUTER, INC. BE LIABLE FOR DIRECT, INDIRECT, SPECIAL, INCIDENTAL, SPECULATIVE OR CONSEQUENTIAL DAMAGES ARISING FROM THE USE OR INABILITY TO USE THIS PRODUCT OR DOCUMENTATION, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. IN PARTICULAR, SUPER MICRO COMPUTER, INC. SHALL NOT HAVE LIABILITY FOR ANY HARDWARE, SOFTWARE, OR DATA STORED OR USED WITH THE PRODUCT, INCLUDING THE COSTS OF REPAIRING, REPLACING, INTEGRATING, INSTALLING OR RECOVERING SUCH HARDWARE, SOFTWARE, OR DATA.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Supermicro's total liability for all claims will not exceed the price paid for the hardware product.

FCC Statement: Refer to Supermicro's web site for FCC Compliance Information.

California Best Management Practices Regulations for Perchlorate Materials: This Perchlorate warning applies only to products containing CR (Manganese Dioxide) Lithium coin cells. "Perchlorate Material-special handling may apply. See www.dtsc.ca.gov/hazardouswaste/perchlorate".

WARNING: Handling of lead solder materials used in this product may expose you to lead, a chemical known to the State of California to cause birth defects and other reproductive harm.

Manual Revision 1.0

Release Date: Oct. 25, 2012

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2012 by Super Micro Computer, Inc.
All rights reserved.

Printed in the United States of America

Preface

About this User's Guide

This user guide is written for system integrators, PC technicians and knowledgeable PC users who intend to configure the IPMI settings supported by the Renesas SH7757 Baseboard Management Controller (BMC) embedded in Supermicro's motherboards. It provides detailed information on how to configure the IPMI settings supported by the Renesas SH7757 BMC chip.

User's Guide Organization

Chapter 1 provides an overview to the IPMI Controller. It also introduces the features and the functionality of IPMI.

Chapter 2 provides detailed instructions on how to configure the IPMI settings supported by the Renesas SH7757 Controller.

Appendix A provides detailed information on Flash Tools.

Conventions Used in the User's Guide

Special attention should be given to the following symbols for proper IPMI configuration.

Warning: Important information given to avoid IPMI configuration errors.



Note: Additional Information given to ensure correct IPMI configuration and proper system setup.

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.

Tel: +1 (408) 503-8000

Fax: +1 (408) 503-8008

Email: marketing@supermicro.com (General Information)
support@supermicro.com (Technical Support)

Web Site: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands

Tel: +31 (0) 73-6400390

Fax: +31 (0) 73-6416525

Email: sales@supermicro.nl (General Information)
support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)

Asia-Pacific

Address: Super Micro Computer, Inc.
4F, No. 232-1, Liancheng Rd
New Taipei City 235
Taiwan

Tel: +886-(2) 8226-3990

Fax: +886-(2) 8226-3991

Web Site: www.supermicro.com.tw

Technical Support:

Email: support@supermicro.com.tw

Tel: +886-(2)-8226-3990

Notes

Table of Contents

Preface

Chapter 1 Introduction..... 1-1

1-1	An Overview of the Renesas SH7757 BMC Controller	1-1
	Renesas SH7757 Peripheral Functions.....	1-1
	Other Renesas SH7757 Subsystem Features Supported.....	1-1
1-2	Block Diagram.....	1-2
1-3	A Brief Introduction to the IPMI.....	1-2
1-4	Motherboards Supported	1-3
1-5	An Important Note to the User.....	1-3

Chapter 2 Configuring the IPMI Settings..... 2-1

2-1	Configuring BIOS IPMI Settings.....	2-1
	Enabling COM Port for SOL (IPMI)	2-1
	Enabling All Onboard USB ports.....	2-2
	Configuring IP and MAC Addresses Using the BIOS.....	2-2
	Configuring IP/MAC Addresses Using the IPMICFG Utility.....	2-4
	Accessing the Baseboard Management Controller	2-5
2-2	Accessing the Remote Server from a Browser on Your Computer.....	2-6
	2.2.1 To Log In	2-7
	2.2.2 IPMI Main Page	2-8
	2.3 FRU Information.....	2-11
	2.4 Server Health	2-13
	2.5 Configuration	2-19
	2.6 Remote Control.....	2-54
	2.7 Maintenance.....	2-71
	2.8 Miscellaneous	2-77

Appendix A Flash Tools A-1

A-1	Overview	A-1
A-2	Flashing the BMC Firmware in the DOS Environment.....	A-1
	Examples.....	A-2
A-3	Flashing the BMC Firmware in the Windows Environment	A-3
	Examples.....	A-4
A-4	Flashing the BMC Firmware in the Linux Environment.....	A-6
	Examples.....	A-7

Chapter 1

Introduction

1-1 An Overview of the Renesas SH7757 BMC Controller

The Renesas SH7757 controller is integrated with a robust set of peripheral functions that are necessary for a Baseboard Management Controller (BMC). The RISC (Reduced Instruction Set Computing) CPU core built into the Renesas SH7757 controller offers the user a superb solution to manage PC server systems with great efficiency.

The Renesas SH7757 BMC supports 256 GB of memory and a speed of up to 576 MHz. The motherboard also supports an additional 32 MB of Flash memory to store the firmware. The controller provides on-chip Memory Management Unit (MMU), which yields up to 4 GB of virtual address space.


Renesas SH7757 Periperal Functions

The Renesas SH7757 supports a variety of functions to manage a system. To enable display redirection and recreation for remote system management, the Renesas SH7757 graphics controller integrates a PCI 3.0 Matrox G200 interface with a video data compressor to support Keyboard/Video/Mouse (KVM). The Renesas SH7757 also supports an I²C bus interface, and LPC bus interface, two ethernet controllers, serial communication interfaces, and USB media hosting.

Other Renesas SH7757 Subsystem Features Supported

- Network Connections: Two Gigabit connections (one dedicated LAN connection and one shared LAN with an onboard LAN controller)
- 1600 x 1200 resolution at 32 bpp (bits per pixel) and 75 Hz
- 1680 x 1050 widescreen resolution at 32bpp and 60 Hz
- Hardware video compression with maximum resolution of 1600 x 1200 with 16-bit color (for KVM)
- Shared-memory type 16 MB frame buffer controller

1-2 Block Diagram



The following diagram represents a typical system setup for the Renesas SH7757 Controller.

1-3 A Brief Introduction to the IPMI

The Intelligent Platform Management Interface (IPMI) Specification provides remote access to multiple users from different locations for networking. It also allows a system administrator to monitor system health and manage computer events from a remote location.

IPMI operates independently of the operating system. The Renesas SH7757 BMC Controller provides connections between other onboard system components, allowing for network interfacing via remote management. With the Renesas SH7757 Controller and the IPMIView software, an administrator can access, monitor, diagnose and manage a Supermicro computer system from a remote site. It also provides

remote access to multiple users from different locations for system maintenance and network management.

1-4 Motherboards Supported

The Renesas SH7757 Controller is supported by the motherboards listed below. If your motherboard is not included in the list, please refer to the motherboard product page on our website at www.supermicro.com and download the right BMC/IPMI user's guide for your motherboard.

- X9DRG-QF
- X9DRW-3F
- X9DRW-iF

1-5 An Important Note to the User

The graphics shown in this user's guide were based on the latest information available at the time of publishing of this guide. The IPMI screens shown on your computer may or may not look exactly like the screen shown in this user's guide.

Notes

Chapter 2

Configuring the IPMI Settings


Supermicro motherboards, configured with the Renesas SH7757 BMC Controller, allow the user to access, monitor, and manage multiple systems remotely. The necessary firmware for accessing and configuring the IPMI settings are available on Supermicro's website at <http://www.supermicro.com/products/nfo/ipmi.cfm>. This section provides detailed information on how to configure the IPMI settings.

2-1 Configuring BIOS IPMI Settings

Before configuring IPMI, follow the instructions below to configure the system BIOS settings.

Enabling COM Port for SOL (IPMI)

1. Press the key at bootup to enter the BIOS Setup utility.
2. Navigate to the **Advanced** menu, select *Serial Port Console Redirection* and press <Enter>.
3. Make sure that the COM port for SOL (COM2 or COM3) is set to [Enabled], as shown below. If the COM port is set to Disabled, select the port for SOL and press <Enter> to set it to Enabled. (For IPMI to work, console redirection for SOL/COM2 is set to Enabled by default.)



Enabling All Onboard USB ports

1. Press the key at bootup to enter the BIOS Setup utility.
2. From the **Advanced** menu, navigate to *Chipset Configuration* and press <Enter>.
3. From the *Chipset Configuration* submenu, select *South Bridge* and press <Enter>.
4. Make sure that *All USB Devices* is set to [Enabled]. If not, select *All USB Devices* and press <Enter> to set as enabled. (This is required for KVM to work properly.)




Configuring IP and MAC Addresses Using the BIOS

1. Press the key at bootup to enter the BIOS Setup Utility.
2. From the **IPMI** menu, navigate to *BMC network configuration* and press <Enter>.
3. Select *Configuration Address Source* and press <Enter> to display the address source options, which are DHCP and Static. If Static is selected, you will need to know the IP address of this computer and enter it to the system manually in the field. If DHCP is selected, the BIOS will search for a DHCP (Dynamic Host Configuration Protocol) server in the network that it is attached to and request the next available IP address for this computer.

The following items are assigned IP addresses automatically if DHCP is selected, or can be configured manually if Static is selected:

- **Station IP Address:** This item displays the Station IP address for this computer. This should be in decimal and in dotted quad form (i.e., 192.168.10.253).
 - **Subnet Mask:** This item displays the sub-network that this computer belongs to. The value of each three-digit number separated by dots should not exceed 255.
 - **Station MAC Address:** This item displays the Station MAC address for this computer. Mac addresses are 6 two-digit hexadecimal numbers.
 - **Gateway IP Address:** This item displays the Gateway IP address for this computer. This should be in decimal and in dotted quad form (i.e., 192.168.10.253).
4. Make sure that *Update IPMI LAN configuration* is set to Yes. If it is not, select *Update IPMI LAN configuration* and press <Enter> to change the setting to Yes. This will allow any changes made to the Configuration Address Source to take effect at the next system boot.



Configuring IP/MAC Addresses Using the IPMICFG Utility

1. Go to www.supermicro.com/support and click on **Supermicro FTP Site** (right side of the page).
2. ACCEPT the license agreement and go to **utility > IPMICFG**.
3. Select **DOS** and save a copy of the IPMICFG utility file to a bootable USB.
4. Boot the system into the DOS USB and run the IPMICFG utility.
5. Type IPMICFG and press <Enter> for a list of commands (provided below).



Note: For additional IPMI configuration information, see the "readme file included with the IPMICFG utility at the FTP site.

IPMICFG Version 1.35 (Build 2010-04-28) Copyright 2010 Super Micro Computer, Inc. Usage: IPMICFG Parameters (Example: IPMICFG -m 172.31.1.84)

-m	Shows IP and MAC
-m IP	Sets IP (format: ###.###.###.###)
-a MAC	Sets MAC (format: ##.##.##.##.##.##)
-k	Shows Subnet Mask
-k Mask	Sets Subnet Mask (format: ###.###.###.###)
-dhcp	Gets the DHCP status
-dhcp on	Enables the DHCP
-dhcp off	Disables the DHCP
-g	Shows Gateway IP
-g IP	Sets Gateway IP (format: ###.###.###.###)
-r	BMC cold reset
-garp on	Enables the Gratuitous ARP
-garp off	Disables the Gratuitous ARP
-fd	Resets to the factory defaults
-ver	Gets the firmware revision
-vlan	Gets VLAN status
-vlan on (VLANtag)	Enables the VLAN and sets the VLAN tag (If VLAN tag is not given, it uses previously saved value.)
-vlan off	Disables the VLAN
-raw	Sends a RAW IPMI request and print the response. Format: NetFn LUN Cmd [Data1...DataN].
-sdr	Shows SDR records and reading
-sdr del <SDR ID>	Deletes SDR record

-sdr backup <FILE>	Backups SDR to file
-sdr restore <FILE>	Restores SDR from file
-sdr ver [<V1><v2>]	Retrieves and sets SDR version (V1, V2)
-sel info	Shows SEL info
-sel list	Shows SEL records
-sel del	Deletes all SEL records
-fru info	Shows FRU inventory area info
-fru list	Shows all FRU values
-fru help	Shows FRU Write help
-fru cthelp	Shows chassis type code
-fru <Field>	Shows FRU field value
-fru <Field> <Value>	Writes FRU
-fru backup <File>	Backs up FRU to file
-fru restore <File>	Restores FRU from file
-fru ver [<V1> <V2>]	Retrieves and sets FRU version (V1, V2)

Accessing the Baseboard Management Controller


1. Connect a LAN cable to the dedicated IPMI LAN port or the onboard LAN1 port.
2. Choose a computer connected to the same network and open the IPMIView utility.
3. Go to File > New > System to add a new system.
4. Select the system from the IPMI Domain. Enter the Login ID and Password to login to the IPMIView utility. (The Supermicro default username and password are ADMIN).

2-2 Accessing the Remote Server from a Browser on Your Computer

1. Connect a LAN cable to the dedicated IPMI LAN port or the onboard LAN1 port.
2. Choose a computer that is connected to the same network and open the browser.
3. Enter the IP address of the server that you want to connect to in the address bar of your browser.
4. Once your machine is connected to the remote server, the Log-In screen, as shown on the next page, will display.

2.2.1 To Log In

Once you are connected to the remote server, the following screen will display.




1. Enter your Username and Password (Supermicro default username and password is ADMIN).
2. Click the Login button to display the main page (shown on the next page).
3. If you forget your password, enter your Username then click on the "Forgot Password?" link. A new password will be generated and sent to the email ID associated with the Username.
4. The required browser settings are listed below the Login fields. Make sure that all the listed requirements are met before continuing. For further information on these settings, click the "How to ?" link (the blue question mark).

 **Note 1:** To use the IPMIView utility to access BMC/IPMI settings, refer to the IPMIView User's Guide for instructions.

Note 2: Once you have logged into the BMC using the default password, be sure to change your password for system security.

2.2.2 IPMI Main Page

Once you are logged into the IPMI utility, the IPMI Main page will display as shown below.



The IPMI screen contains the following sections:

- The Menu Bar (#1 above)
- The Host Identification Window (#2 above)
- The Main Display area (#3 above)

1. Menu Bar

The menu bar consist of the following menu items:

Menu Bar	
Summary	This menu displays system information and a remote console preview.
FRU Information	This menu displays information from the BMC FRU file.
Server Health	This menu displays server health monitoring status.
Configuration	This menu allows the user to configure the IPMI settings.
Remote Control	This menu allows the user to launch Remote Console, perform power control, or launch SOL console.
Maintenance	This menu allows the user to update the firmware and BIOS, restore factory defaults, and make changes to the System Admin account.
Miscellaneous	This menu allows the user to view post snooping codes, view power information, and enable/disable UID.
HELP	This provides a basic description for each feature on the page.

Above the HELP menu are several quick button options for the following functions:

- **Refresh** - Click this to refresh the page.
- **Print** - Click this to print the page.
- **Logout** - Click this to logout from the IPMI utility.

2. The Host Identification Window

The Host Identification window at the top center of the IPMI screen displays the name and IP address of the host server and the name and privilege level of the logged-in user.

3. The Main Display Area

This area displays the body of information associated with a menu selection. The Summary menu, which provides overall information regarding the status of the server, is shown in the main display area after you log in. The following information is included in the Summary menu.

Device Information

- **Firmware Revision:** Displays the current firmware revision number
- **Firmware Build Time:** Displays the time and the date when this version of firmware was built

Network Information

To edit the network information, click Edit. This will bring you to the Network Settings screen in the Configuration submenu. For more information about Network Settings, see section 2.5.9.

- **MAC Address:** Displays the MAC address of the IPMI
- **V4 Network Mode:** Displays the v4 network mode (Disable, Static or DHCP) of the IPMI
- **IPv4 Address:** Displays the IPv4 address of the IPMI (not displayed if V4 Network Mode is disabled)
- **V6 Network Mode:** Displays the v6 network mode (Disable, Static or DHCP) of the IPMI
- **IPv6 Address:** Displays the IPv6 address of the IPMI (not displayed if V6 Network Mode is disabled)

Remote Control

A preview screen of the host server displays in the window of this section. To reload the preview screen, click the Refresh button in the preview window. To redirect and manage the host server remotely, click the Launch button to launch the Java redirection window (JViewer).

System Overall Health

This section displays the status and reading of all available sensors on the server. The Status column will display one of the following three states:

-  = Normal State
-  = Warning State
-  = Critical State

For more detailed information about the sensors, click the *Detail* link. For information on a specific sensor, click the magnifying glass icon next to the sensor.

 **Note:** The Details link and the magnifying glass icon will jump you to the Sensor Readings page (Server Health > Sensor Readings). See section 2.4.1. for more information.

Event Logs Pie

This section displays a pie chart illustration of all events detected by the sensors as well as the available space remaining in logs. To view a list of events for a specific item, click the corresponding color-coded rectangle.

2.3 FRU Information

This feature allows the user to view the contents of the BMC FRU file. Click *FRU Information* in the menu bar to display a screen similar to the one shown below.

SUPERMICR®

Host Identification
 Server: SMC0026900FL78D (172.31.8.255)
 User: ADMIN (Administrator)

Summary | **FRU Information** | Server Health | Configuration | Remote Control | Maintenance | Miscellaneous

Field Replaceable Unit(FRU)

This page gives detailed information for the various FRU devices present in this system.

Basic Information:

FRU Device ID	0
FRU Device Name	BMC_FRU

Chassis Information:

Chassis Information Area Format Version	1
Chassis Type	Unspecified
Chassis Part Number	
Chassis Serial Number	
Chassis Extra	

Board Information:

Board Information Area Format Version	1
Language	0
Manufacture Date Time	Wed Jun 22 09:51:00 2011
Board Manufacturer	Supernico
Board Product Name	

The FRU Information menu contains the following items:

Basic Information

- FRU Device ID: Choose the desired device ID from the drop-down list.
- FRU Device Name: Displays the name of the FRU device selected.

Chassis Information

- Chassis Information Area Format Version
- Chassis Type
- Chassis Part Number
- Chassis Serial Number
- Chassis Extra

Board Information

- Board Information Area Format Version
- Language
- Manufacture Date Time
- Board Manufacturer
- Board Product Name
- Board Serial Number
- Board Part Number
- FRU File ID
- Board Extra

Product Information

- Product information Area Format Version
- Language
- Manufacturer Name
- Product Name
- Product Part Number
- Product Version
- Product Serial Number
- Asset Tag
- FRU File ID
- Product Extra

2.4 Server Health

This feature allows the user to view Server Health Information. The Server Health submenu contains the following items:

- Sensor Readings
- Event Log
- System and Audit Log

Click *Server Health* to display the submenu as shown below.

The screenshot shows the SUPERMICR BMC/IPMI interface. At the top, there is a 'Host Identification' box showing 'Server: ()' and 'User: ADMIN (Administrator)'. Below this is a navigation menu with 'Sensor Readings' selected. The main content area is titled 'Sensor Readings' and contains a table of sensor data. To the right of the table, there is a section for 'CPU1 TEMP: Low' with 'Thresholds for this sensor' and a 'Graphical View of this sensor's events' section.

Sensor Name ▲	Status ▲	Current Reading ▲
CPU1 TEMP	Normal	Low
CPU2 TEMP	Not Available	Not Available
SYS TEMP 1	Normal	22 ° C
SYS TEMP 2	Normal	26 ° C
PCH TEMP	Normal	43 ° C
CPU1 Vcore	Normal	1.072 Volts
CPU2 Vcore	Not Available	Not Available
VDIMM AB	Normal	1.488 Volts
VDIMM CD	Normal	1.488 Volts
VDIMM EF	Not Available	Not Available
VDIMM GH	Not Available	Not Available
VTT	Normal	1.056 Volts
VBAT	Normal	3.072 Volts
1.5V	Normal	1.488 Volts
12V	Normal	12.19 Volts
3.3VSB	Normal	3.312 Volts
3.3v	Normal	3.264 Volts
5V	Normal	5.056 Volts

CPU1 TEMP: Low

Thresholds for this sensor

Lower Non-Recoverable (LNR): N/A
 Lower Critical (LC): N/A
 Lower Non-Critical (LNC): N/A

Graphical View of this sensor's events

LNR	(0)
LC	(0)
LNC	(0)
UNR	(0)

2.4.1 Sensor Readings

Click this item to display all sensor readings and their thresholds as shown below.

The screenshot shows the SUPERMICR IPMI web interface. At the top, there's a navigation bar with tabs: Summary, FRU Information, Server Health, Configuration, Remote Control, Maintenance, Miscellaneous, and HELP. The main content area is titled "Sensor Readings". Below the title, there's a note: "All sensor related information will be displayed here. Double click on a record to toggle (ON / OFF) the live widget for that particular sensor." Below this, there's a dropdown menu "All Sensors" (1) and a "Sensor Count: 26 sensors" indicator. The main table lists various sensors. The "CPU1 Vcore" sensor is selected, and its details are shown on the right. The table has columns for "Sensor Name" (2), "Status" (3), and "Current Reading" (4). The "CPU1 Vcore" row shows a status of "Normal" (5) and a reading of "1.04 Volts" (7). To the right of the table, there's a "Thresholds for this sensor" section (8) with three rows: "Lower Non-Recoverable (LNR): 0.824 Volts", "Lower Critical (LC): 0.592 Volts", and "Lower Non-Critical (LNC): 0.56 Volts". Below this is a "Graphical View of this sensor's events" section (11) with a bar chart showing zero entries. At the bottom right, there's a "View this Event Log" button (12) and a "Live Wootser On/Off" button (13).


1. Use the drop-down list to display readings for a particular group of sensors. You can also click on a specific record to display more information such as threshold tolerances and a graphical view of associated events. Sensor selections in the drop-down list include:

- **All Sensors:** This item displays the readings for all sensors
- **Temperature Sensors:** This item displays the system temperature.
- **Voltage Sensors:** This item displays the following items: CPU Vcore, DIMM voltages, +3.3V, +3.3VSB, +1.5V, +12V, +5V and VBAT (Battery Voltage).
- **Fan Sensors:** This item displays the readings of the onboard fans.
- **Physical Security:** This item displays the readings of the physical security (i.e. chassis intrusion events).
- **Power Supply:** This item displays the status of power supply failure monitoring.

2. Sensor Name: This item displays the name of the item being monitored.
3. Status: This item displays the status of the sensor item.
4. Current Reading: This item displays the reading of the sensor.


5. Lower Non-Recoverable (LNR): This is the low threshold of a non-recoverable item. Any item with a reading below this point will **not** be recovered.
6. Lower Critical (LC): This is the low threshold of a critical item. Any item with a reading below this threshold is in a critical state.
7. Lower Non-Critical (LNC): This is the low threshold of a non-critical item. Any item with a reading above this threshold is **not** in a critical state.
8. Upper Non-Recoverable (UNR): This is the high threshold of a non-recoverable item. Any item with a reading above this point will **not** be recovered.
9. Upper Critical (UC): This is the high threshold of a critical item. Any item with a reading above this threshold is in a critical state.
10. Upper Non-Critical (UNC): This is the high threshold of a non-critical item. Any item with a reading below this threshold is **not** in a critical state.
11. This area provides a graphical view of the selected sensor's events.
12. View this Event Log: Click this button to view the event log for the selected sensor.
13. Live Widget: Toggle Live Widgets on or off. Live widgets can track the behavior of a sensor over a specific span of time and at defined intervals. The widget displays the results as a line graph. Multiple widgets may be open at once and will remain visible while you navigate through other menu selections. Turning a live widget On will open a live widget window similar to the image shown below.

 **Note:** Alternatively, a live widget can be opened by double-clicking on an applicable sensor in the list.



2.4.2 Event Log

Click this item from the Server Health submenu to display all event log readings, as shown below.



1. From the drop-down menu select an event category to show the event log, which includes the following categories: All Events, Sensor-Specific Events, BIOS-Generated Events, and System-Management Software Events. In addition to these events, it is normal to see boot-up and shutdown events generated by the installed system software (OS). The table below lists examples of these types of events.

Sensor Type	Event
OS Boot	A: boot completed
	C: boot completed
	PXE boot completed
	Diagnostic boot completed
	CD-ROM boot completed
	ROM boot completed
	Boot completed - boot device not specified
OS Stop/Shutdown	Stop during OS load/initialization, Unexpected error during system startup, Stopped waiting for input or power cycle/reset
	Run-time stop (a.k.a 'core dump', 'blue screen')
	OS graceful stop (system powered up, but normal OS operation has shut down and system is awaiting reset pushbutton, power cycle or other external input)

2. Filter by: From the drop-down menu, select the sensor type to display.
3. BMC Timezone: Displays the events using the BMC UTC Offset timestamp.

4. Client Timezone: Displays the events using the Client UTC timestamp.
5. Event ID: This item displays the event ID of this event.
6. Time Stamp: This item displays the time that the event occurred.
7. Sensor Name: This item indicates the name of the sensor (device) to which the event has occurred.
8. Sensor Type: This item indicates the type of the event.
9. Description: This item provides a brief description of the event.
10. Event Log: This item indicates the number of events included on the event log.
11. Clear All Event Logs: Click this button to clear the event log.

2.4.3 System and Audit Log

Click this item from the Server Health submenu to display all system and audit logs that occurred as shown below.



Note: To display log entries in this submenu, logs must first be configured. To configure logs, click Configuration in the main menu, then click System and Audit Log (see section 2.5.16).

The screenshot shows the 'System & Audit Logs' page. At the top, there is a navigation bar with tabs for 'System Log' (1) and 'Audit Log' (2). Below the tabs is a 'Filter by:' dropdown menu (3) currently set to 'Warning'. The main content is a table of log entries with columns: 'Event ID' (4), 'Time Stamp' (5), 'HostName' (6), and 'Description' (7). The table contains 11 rows of log data.


Event ID	Time Stamp	HostName	Description
1	Feb 2 11:34:26	SMC022500F78D	IPMIMan: [513 V4ARNING]@PMBRC: c:675@PMBRC: Unable to send a IPMI Response
2	Feb 2 11:53:29	SMC022500F78D	weblog: [1018 V4ARNING]@sensor_helpers.c:392@sensor reading number format is non-analog!
3	Feb 2 11:53:29	SMC022500F78D	last message repeated 5 times
4	Feb 2 11:57:23	SMC022500F78D	weblog: [1018 V4ARNING]@sensor_helpers.c:392@sensor reading number format is non-analog!
5	Feb 2 11:58:28	SMC022500F78D	last message repeated 12 times
6	Feb 2 11:58:28	SMC022500F78D	last message repeated 5 times
7	Feb 2 11:58:30	SMC022500F78D	IPMIMan: [513 V4ARNING]@PMBRC: c:551@PMBRC: Error sending IPMB packet to Slave 0x16 ErrorCode: 80000081
8	Feb 2 11:58:30	SMC022500F78D	IPMIMan: [513 V4ARNING]@PMBRC: c:675@PMBRC: Unable to send a IPMI Response
9	Feb 2 11:58:30	SMC022500F78D	weblog: [1018 V4ARNING]@sensor_helpers.c:392@sensor reading number format is non-analog!
10	Feb 2 11:58:54	SMC022500F78D	last message repeated 17 times
11	Feb 2 12:00:16	SMC022500F78D	IPMIMan: [513 V4ARNING]@PMBRC: c:551@PMBRC: Error sending IPMB packet to Slave 0x16 ErrorCode: 80000081
12	Feb 2 12:00:16	SMC022500F78D	IPMIMan: [513 V4ARNING]@PMBRC: c:675@PMBRC: Unable to send a IPMI Response
13	Feb 2 12:00:16	SMC022500F78D	IPMIMan: [513 V4ARNING]@PMBRC: c:551@PMBRC: Error sending IPMB packet to Slave 0x16

1. System Log: Click this tab to view system events.
2. Audit Log: Click this tab to view audit events.
3. Filter By: This drop-down is visible only under the System Log tab. Selection options include Alert, Critical, Error, Notification, Warning, Debug, Emergency, and Information.
4. Event ID: This item displays the event ID of this event.
5. Time Stamp: This item displays the time that the event occurred.
6. HostName: This item displays the hostname of the device where the event occurred.
7. Description: This item provides a brief description of the event.

To clear the System/Audit logs, click the *Clear Event Logs* button at the bottom of the list.

2.5 Configuration

This feature allows the user to configure various network settings. Click *Configuration* in the main menu to display submenu items shown below.



Select an item to configure its settings. The Configuration submenu contains the following items:

- **Active Directory:** This item allows the user to configure settings to authenticate and access the Active Directory server.
- **Alert:** This item allows the user to configure settings for Event Filter, Alert Policy, and LAN Destination.
- **Date & Time:** This item allows the user to configure Date & Time settings and synchronize with NTP server and role devices.
- **DNS:** This item allows the user to configure DNS settings.
- **LDAP:** This item allows the user to configure LDAP (Lightweight Directory Access Protocol) settings.
- **Mouse Mode:** This item allows the user to set the remote console mouse mode.
- **Fan Speed Mode:** This item allows the user to modify fan speed mode.
- **Network:** This item allows the user to configure LAN, IPv4, IPv6, and VLAN settings.
- **PAM Order:** This item allows the user to configure PAM (Pluggable Authentication Module) ordering.
- **RADIUS:** This item allows the user to configure RADIUS settings.


- Remote Session: This item allows the user to configure KVM and Virtual Media encryption settings for the next redirection session.
- Services: This item allows the user to configure services running on the BMC.
- SMTP: This item allows the user to configure Simple Mail Transfer Protocol (SMTP) settings. To set up an email alert, enter the IP address of your mail server in the SMTP.
- SSL: This item allows the user to configure Secure Sockets Layer (SSL) certificate settings.
- System and Audit Log: This item allows the user to configure system event logging.
- Users: This item allows the user to add, delete and modify user data, such as username, password, and privileges.
- Virtual Media: This item allows the user to set the number of virtual media devices.



Note: To mount virtual media, launch the remote console (JViewer) and click *Media > Virtual Media Wizard* (see section 2.6.1.e for more information).

2.5.1 Active Directory

The active directory stores network and domain data. It also offers a variety of functions that include providing and organizing object information for quick retrieval and easy access for the end user and administrator. Click *Active Directory* in the Configuration submenu to display and configure Active Directory settings.



1. **Advanced Settings:** If Active Directory is currently disabled, click this button to enable it. For more information on enabling the active directory, see section 2.5.1a.
2. **Role Group ID:** This item displays the role group ID.
3. **Group Name:** This item displays the name of the role group, which consists of a string of 255 alpha-numeric characters.
4. **Group Domain:** This item displays the domain of the role group, which consists of a string of 255 alpha-numeric characters.
5. **Group Privilege:** This item displays the privilege level assigned to the role group.
6. **Add Role Group:** Click this button to add a new role group (see section 5.1.b).
7. **Modify Role Group:** Click this button to modify a selected role group. A role group may also be modified by double-clicking on its slot.
8. **Delete Role Group:** Click this button to delete an existing role group.

2.5.1.a Active Directory - Advanced Settings

This feature allows the user to configure Active Directory-Advanced settings. Click the *Advanced Settings* button (see previous page) to display the following window.

1. Active Directory Authentication: Click the Enable checkbox to activate and configure the Active Directory server information below.
2. User Domain Name: This field allows the user to enter the user domain name.
3. Time Out: This field allows the user to indicate the time (seconds) to wait before ending an Active Directory query. The range is 15 sec ~ 300 sec.
4. Domain Controller Server Addresses 1~3: These items allow the user to enter the IP addresses for the Domain Controller Servers 1~3. At minimum, one address must be configured.




Note: Server address supports IPv4 and IPv6 Address format.

After the required information is entered, click the Save button to save the information you've entered, or click Cancel to abort. Either selection will return you to the Active Directory Settings page.

2.5.1.b Active Directory - Adding and Modifying Role Groups

This feature allows the user to add a role group to the Active Directory Settings page. Select a blank row from the Role Group list and click *Add Role Group* to display the window below.

 **Note:** Advanced Active Directory settings must be configured to enable the Add Role Group button. See section 2.5.1.a for more information.



The screenshot shows a dialog box titled "Add Role Group" with a close button in the top right corner. The dialog contains three input fields: "Role Group Name" (a text box), "Role Group Domain" (a text box), and "Role Group Privilege" (a dropdown menu with "Administrator" selected). At the bottom right of the dialog are two buttons: "Add" and "Cancel". Red circles with numbers 1 through 5 are overlaid on the image to indicate the steps: 1 points to the "Role Group Name" label, 2 points to the "Role Group Domain" label, 3 points to the "Role Group Privilege" label, 4 points to the "Add" button, and 5 points to the "Cancel" button.

1. Role Group Name: Enter a name for the role group.
2. Role Group Domain: Enter the domain location of the role group.
3. Role Group Privilege: Assign a privilege level for the role group. The options are Administrator, Operator, User, OEM Proprietary, and No Access.
4. Click the Add button to save the role group settings and return to the Active Directory Settings page.
5. Click the Cancel button to abort and return to the Active Directory Settings page.

2.5.2 Alerts

This feature allows the user to configure Alert settings. Click *Alerts* in the Configuration submenu to display the Alert Management page shown below.

Host Identification
Server: SMCX9SMM00ETMD (172.31.8.266)
User: ADMIN (Administrator)

Summary FRU Information Server Health **Configuration** Remote Control Maintenance Miscellaneous HELP

Alert Management

Use this page to configure Event Filter Policy and LAN Destination. To delete or modify an entry, select it in the list and press "Delete" or "Modify". To add a new entry, select an unconfigured slot and press "Add".

Event Filter Alert Policy LAN Destination

Configured Event Filter count: 15

PEF ID ▲	Filter Configuration ▲	Event Filter Action ▲	Event Severity ▲	Sensor Name ▲
2	Enabled	[Alert]	Unspecified	Any
3	Enabled	[Alert]	Unspecified	Any
4	Enabled	[Alert]	Unspecified	Any
5	Enabled	[Alert]	Unspecified	Any
6	Enabled	[Alert]	Unspecified	Any
7	Enabled	[Alert]	Unspecified	Any
8	Enabled	[Alert]	Unspecified	Any
9	Enabled	[Alert]	Unspecified	Any
10	Enabled	[Alert]	Unspecified	Any
11	Enabled	[Alert]	Unspecified	Any

Add Modify Delete

1. **Event Filter:** This tab displays the configured event filters and available slots. Add, Modify or delete event filter entries from here (see section 2.5.2.a). There is a default of 15 preconfigured event slots. A maximum of 40 total slots are available.
2. **Alert Policy:** This tab displays the configured alert policies and available slots. Add, Modify or delete alert policy entries from here (see section 2.5.2.b). A maximum of 60 total slots are available.
3. **LAN Destination:** This tab displays the configured LAN destinations and available slots. Add, Modify or delete LAN destination entries from here (see section 2.5.2.c). A maximum of 15 total slots are available.
4. Click the **Add** button to configure an empty slot.
5. Click the **Modify** button to change settings for a configured slot.
6. Click the **Delete** button to clear the configured slot.

2.5.2.a Alerts - Adding and Modifying Event Filters

To add a new event filter, click the Event Filter tab, select an empty slot, and click the Add button at the bottom of the page. To modify an event filter, select a configured slot and click the Modify button. Whether adding or modifying an event filter, virtually the same window is displayed, similar to the image below.

The screenshot shows the 'Add Event Filter entry' form in the SUPERMICR web interface. The form is organized into several sections:

- Event Filter Configuration:** PEF ID (16), Filter Configuration (Enable checked), Event Severity (Unspecified).
- Filter Action configuration:** Event Filter Action (Alert checked), Power Action (None), Alert Policy Number.
- Generator ID configuration:** Generator ID Data (Raw Data checked), Generator ID 1 (0x0), Generator ID 2 (0x0), Event Generator (Slave Address or System Software ID).
- Channel Number:** 0
- IPMB Device LUN:** 1
- Sensor configuration:** Sensor Type, Sensor Name (All Sensors), Event Options (Sensor Events).
- Event Data configuration:** Event Trigger (0).

Enter the required configuration information and settings for the following fields:

Event Filter Configuration

- **PEF ID:** This number (read only) indicates the PEF ID for this entry.
- **Filter Configuration:** To enable PEF settings, check the Enable box.
- **Event Severity:** Selects the event severity level. The options are Unspecified, Monitor, Information, Normal, Non-Critical, Critical, and Non-Recoverable.

Filter Action Configuration

- **Event Filter Action:** This field, which enables the PEF alert action, is mandatory and is checked by default.
- **Power Action:** Select a power action. The options are None, Power Down, Power Reset, and Power Cycle.
- **Alert Policy Number:** Select between the available configured policy numbers. To create additional alert policies, go to Configuration > Alert > Alert Policy. For more information, see section 2.5.2.b.

Generator ID Configuration

- Generator ID Data: Check the Raw Data box to enter raw data for the Generator ID.



Note: Checking the Raw Data box will disable (grey-out) the Event Generator field and its associated fields. Unchecking the Raw Data box will disable the Generator ID 1 and ID 2 fields.

- Generator ID 1, ID 2: Enter raw data for generator ID 1 and ID 2.
- Event Generator: Select Slave Address if the event was generated from IPMB. Select System Software if the event was generated from system software.
- Slave Address/Software ID: Enter the Slave Address or the System Software ID.
- Channel Number: Select the channel number that the event was received over. If the event was received through the system interface, primary IPMB, or generated internally by the BMC, select channel 0.
- IPMB Device LUN: Select the appropriate IPMB device LUN if the event was generated by IPMB.

Sensor Configuration

- Sensor Type: Select the type of sensor will activate the event filter action.
- Sensor Name: Select a sensor name from the drop-down list.
- Event Options: Select either sensor related events or all events.

Event Data Configuration

- Event Trigger: Use this field to assign an event/reading type value. The range is from 1 to 255.
- Event Data 1 AND Mask: Use this field to indicate compared or wildcarded bits. The range is from 1 to 255. (This description also applies to Event Data 2 AND Mask & Event Data 3 AND Mask.)
- Event Data 1 Compare 1 / Compare 2: Use this field to indicate if each bit position's comparison is an exact comparison or not. (This description also applies to Event Data 2 Compare 1/2 & Event Data 3 Compare 1/2.)

Click the Add button to save the new event filter configuration and return to the Event Filter list. Click the Reset button to reset all fields. Click the Cancel button to abort configuration and return to the Event Filter list.

2.5.2.b Alerts - Adding and Modifying Alert Policies

To add a new alert policy, click the Alert Policy tab, select an empty slot from the list, and click the Add button. To modify an alert policy, select a configured slot and click the Modify button. Whether adding or modifying an alert policy, virtually the same window is displayed, similar to the image below.

1. Policy Entry #: The policy entry number is displayed. This field is read only.
2. Policy Number: Use this item to select the policy number that was configured in the Event Filter table (see Alert Policy Number field in section 2.5.2.a).
3. Policy Configuration: Click the Enable checkbox to enable policy settings.
4. Policy Set: Use this item to select a policy set number from the drop-down list. The options are:
 - 0: Always send alert to this destination.
 - 1: If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry in this policy set.
 - 2: If alert to previous destination was successful, do not send alert to this destination. Do not process any more entries in this policy set.
 - 3: If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry that is to a different channel.
 - 4: If alert to previous destination was successful, do not send alert to this destination. Proceed to next entry that is to a different destination type.
5. Channel Number: Select an available number from the drop-down list.

6. Destination Selector: Select a destination from the drop-down list.



Note: You must first configure the LAN destination. Go to Configuration > Alert > LAN Destination (See section 2.5.2.c for more information).

7. Alert String: Click the Event Specific checkbox to query whether or not the Alert String is event specific.

8. Alert String Key: Select a value that will be used to look up the Alert String to send for this Alert Policy.

9. Click the Add button to save the alert policy and return to the Alert Policy list.

10. Click the Cancel button to abort and return to the Alert Policy list.

2.5.2.c Alerts - Adding and Modifying LAN Destinations

To add a new LAN destination, click the LAN Destination tab and select an empty slot from the list, then click the Add button. To modify a LAN destination, select a configured slot and click the Modify button. Whether adding or modifying a LAN destination, a window similar to the image shown below will be displayed.

1. LAN Destination: The LAN destination number is displayed. This field is read only.
2. Destination Type: Select either SNMP Trap or Email Alert for the destination type. If SNMP Trap is selected, the Destination Address field (below) must be populated and SMTP server information must be entered (see section 2.5.14). If Email Alert is selected, the Username, Subject, and Message fields must be populated.
3. Destination Address: Specify the IP address of the system that will receive the alert. Both IPv4 and IPv6 address formats are supported.
4. Username: Select the username to which the email alert will be sent.
 -  **Note:** The user email address must first be configured. Go to Configuration > Users (see section 2.5.17 for more information).
5. Subject: Enter a subject for the email alert that will be sent to the specified user.
6. Message: Enter a message for the email alert that will be sent to the specified user.
7. Click the Add button to save the entry and return to the LAN Destination list.
8. Click the Cancel button to abort and return to the LAN Destination list.

2.5.3 Date and Time

This feature allows the user to modify time and date settings for the host server. Click this item in the Configuration submenu to display the date and time settings as shown below.



1. Date: Enter month, date and year in this row.
2. Time: Enter hour, minute and second in the (hh:mm:ss) format.
3. UTC Timezone: Select from the list of UTC offset values for the NTP server.
4. NTP Server: Enter the name of the NTP server in this field. This field is disabled if the 'Automatically synchronize...' checkbox (see #5) is not checked.
5. Automatically synchronize Date & Time: Check this box to enable synchronization of time and date of the client computer with the NTP server.
6. Refresh: Click this button to refresh the page.
7. Save: Click this item to save any changes done to the Time and Date settings.
8. Reset: Click this button to reset any changes back to the previous values.

2.5.4 DNS

Use this feature to configure DNS settings. Click *DNS* in the Configuration submenu to display the date and time settings as shown below.

The screenshot displays the 'DNS Server Settings' page in the SUPERMICR management interface. At the top, there is a 'Host Identification' box showing 'Server: BMC002500FE1BD (172.31.8.248)' and 'User: ADMIN (Administration)'. Below this is a navigation menu with 'Configuration' selected. The main content area is titled 'DNS Server Settings' and includes a sub-header 'Manage DNS settings of the device.' The settings are organized into several sections:

- Host Configuration:** 'Host Settings' is set to 'Automatic' (dropdown). 'Host Name' is 'BMC002500FE1BD' (text input).
- Register BMC:** 'bond0' is selected. The 'Register BMC' checkbox is checked. Radio buttons for 'Direct Dynamic DNS' (selected) and 'DHCP Client FQDN' are present.
- Domain Name Configuration:** 'Domain Settings' is 'bond0_v4' (dropdown). 'Domain Name' is 'supermicro.com' (text input).
- IPv4 Domain Name Server Configuration:** 'DNS Server Settings' is 'bond0' (dropdown). 'Preferred DNS Server' is '66.120.31.16' (text input). 'Alternate DNS Server' is '66.120.31.170' (text input).
- IPv6 Domain Name Server Configuration:** 'DNS Server Settings' is 'Manual' (dropdown). 'Preferred DNS Server' and 'Alternate DNS Server' are empty text inputs.


'Save' and 'Reset' buttons are located at the bottom right of the configuration area.

The DNS page allows you to configure the following items:

- **Host Settings:** Select between Automatic or Manual. Selecting manual will allow you to enter a host name.
- **Host Name:** If host settings (above) is set to Manual, enter the host name here.
- **Register BMC:** If this box is checked, select the BMC network port to register with this DNS setting.
- **Domain Settings:** Use the drop-down list to make a selection. If you choose DHCP, select v4 or v6 for DHCP servers.
- **Domain Name:** If Domain Settings (above) is set to Manual, enter the domain name here.
- **DNS Server Settings:** Use the drop-down list to make a selection for IPv4 / IPv6 Domain Name Server Configuration.
- **Preferred DNS Server / Alternate DNS Server:** If the DNS Server Settings (above) are set to Manual, enter the preferred/alternate DNS server IP address for IPv4 / IPv6 Domain Name Server Configuration.

2.5.6 LDAP (Light-Weight Directory Access Protocol)

LDAP is an internet protocol used for user authentication. With an LDAP server configured on your network, it can be used to authenticate and manage users. Click *LDAP* in the Configuration submenu to display the following the LDAP settings page shown below.



1. **Advanced Settings:** If LDAP is disabled, click this button to enable it. For more information on enabling active directory, see section 2.5.6a.
2. **Role Group ID:** This item displays the role group ID.
3. **Group Name:** This item displays the name of the role group.
4. **Group Domain:** This item displays the domain of the role group.
5. **Group Privilege:** This item displays the privilege level assigned to the role group.
6. **Add Role Group:** Click this button to add a new role group (see section 5.1.b).
7. **Modify Role Group:** Click this button to modify a selected role group. A role group may also be modified by double-clicking on its slot.
8. **Delete Role Group:** Click this button to delete an existing role group.

2.5.6.a LDAP - Advanced Settings

Use this feature to configure LDAP advanced settings. When you click the Advanced Settings button (see previous page), the below window will display.

Advanced LDAP Settings

1 LDAP Authentication Enable

2 IP Address

3 Port

4 Bind DN

5 Password

6 Search Base

7 Save 8 Cancel

1. LDAP Authentication: Click the Enable checkbox to activate and configure the LDAP authentication information below.
2. IP Address: Enter the IP address of the LDAP server.
3. Port: Enter the LDAP port number. The default port is 389. For a secure connection, the default port is set to 636.
4. Bind DN: This is a string of 4 to 64 alpha-numeric characters used to authenticate the client to the server. For example, dc=administrator, dc=com, ou=login.
5. Password: Enter the password of the LDAP server. The password can not exceed 48 characters and white space is not allowed.
6. Search Base: Enter the search base for the LDAP server. This shows the client which port in the external directory tree to use for doing search. For example, dc=administrator, dc=com, ou=login.



Note: Search base must begin with an alpha-numeric character. Special symbols are allowed.

7. Save: Click this button to save the changes.
8. Cancel: Click this button to abort and return to LDAP Settings page.

2.5.6.b LDAP - Adding and Modifying Role Groups

Use this feature to add a role group to the LDAP Settings page. Select a blank row from the Role Group list and click *Add Role Group* to display the window below.

 **Note:** Advanced LDAP settings must be configured to enable the Add Role Group button. See section 2.5.6.a for more information.

1. Role Group Name: Enter a name for the role group.
2. Role Group Search Base: Enter the path from where the role group is located to Base DN.
3. Role Group Privilege: This item assign a privilege level for the role group. The options are Administrator, Operator, User, OEM Proprietary, and No Access.
4. Click the Add button to save the role group settings and return to the LDAP Settings page.
5. Click the Cancel button to abort and return to the LDAP Settings page.

2.5.7 Mouse Mode

Use this feature to configure how mouse emulation is handled from the local window to the remote screen. Click *Mouse Mode* in the Configuration submenu to display the page below.

Host Identification
Server: SMC092890E7ED (172.31.8.255)
User: ADMIN (Administrator)

Summary FRU Information Server Health Configuration Remote Control Maintenance Miscellaneous HELP

Mouse Mode Settings

Redirection console mouse mode settings can be modified here.

The current Mouse Mode is **ABSOLUTE**.

Set Mode to Absolute (Recommended when server OS is Windows)

Set Mode to Relative (Recommended when server OS is Linux)

Save Reset


- **Absolute Mode:** Check this radio button to send the absolute position of the local mouse to the server. Absolute mode is recommended for Windows OS, Red Hat Enterprise Linux 6 (RHEL6) and above, and Fedora Core 14 (FC14) and above.
- **Relative Mode:** Check this radio button to send the relative calculated mouse position displacement to the server. Relative mode is recommended for FC13 and below, RHEL5 and below, and other Linux distributions.

 **Note:** IPMI is an OS-independent platform, and KVM support is an added feature for IPMI. For your mouse to function properly, configure the Mouse Mode settings (above) according to the remote server's OS type.

Click the Save button to save any changes, or click the Reset button to reset any modification to the original setting.

2.5.8 Fan Speed Mode

Use this feature to modify fan speed settings. Click *Fan Speed Mode* in the Configuration submenu to display the page below.



- Full Speed Mode: Select this option for the fans to provide maximum cooling.
- Standard Mode: Select this option for system fans to operate at predetermined speeds based upon the temperature of the hottest monitored components.
- Optimal Mode: Select this option for system fans to operate at predetermined speeds within each cooling zone, based upon the temperature of the hottest monitored components in each cooling zone.

Click the Save button to save any changes.

2.5.9 Network

Use this feature to configure network settings for the available LAN channels. Click *Network* in the Configuration submenu to display the page below.

The screenshot displays the 'Network Settings' page in the SUPERMICR BMC/IPMI interface. The page is organized into several sections:

- Network Bonding:** Includes a checked 'Enable' checkbox.
- Default Interfaces:** A dropdown menu set to 'Fail Over'.
- LAN Interface:** A dropdown menu set to 'bond0'.
- LAN Settings:** Includes a checked 'Enable' checkbox.
- MAC Address:** A text field displaying '00:25:90:0F:E7:8D'.
- IPv4 Configuration:**
 - 'Obtain an IP address automatically': Checked 'Use DHCP'.
 - 'IPv4 Address': Text field with '172.31.8.255'.
 - 'Subnet Mask': Text field with '255.255.0.0'.
 - 'Default Gateway': Text field with '172.31.0.1'.
- IPv6 Configuration:**
 - 'IPv6 Settings': Includes a checked 'Enable' checkbox.
 - 'Obtain an IP address automatically': Includes a checked 'Use DHCP' checkbox.
 - 'IPv6 Address': Empty text field.
 - 'Subnet Prefix length': Text field with '0'.
 - 'Default Gateway': Empty text field.
- VLAN Configuration:**
 - 'VLAN Settings': Includes a checked 'Enable' checkbox.
 - 'VLAN ID': Text field with '0'.
 - 'VLAN Priority': Text field with '0'.

At the bottom right of the form, there are 'Save' and 'Reset' buttons.

The available network settings are described below:

- **Network Bonding:** Click the Enabled checkbox to activate network bonding and enable the associated configuration fields.
- **Default Interfaces:** Select between Fail Over (default), Dedicated LAN and Shared NCSI.
- **LAN Interface:** Select the desired LAN interface to configure.
- **LAN Settings:** Use this checkbox to enable or disable LAN support for the selected LAN interface.
- **MAC Address:** Displays the MAC address of the LAN interface (read only).

IPv4 Configuration

- **Obtain an IP address automatically:** Click the checkbox to configure the IPv4 address dynamically using DHCP (Dynamic Host Configuration Protocol).
- **IPv4 Address, Subnet Mask, Default Gateway:** If DHCP is not enabled above, use these fields to enter the static address information for the selected interface.

IPv6 Configuration

- IPv6 Settings: Click this checkbox to enable IPv6 support.
- Obtain an IP address automatically: Click the checkbox to configure the IPv6 address dynamically using DHCP (Dynamic Host Configuration Protocol).
- IPv6 Address: If DHCP is not enabled above, enter the static IPv6 address.
- Subnet Prefix length: Enter the subnet prefix length for IPv6 settings. The range is from 0 to 128.
- Default Gateway: Enter the default gateway for the IPv6 settings.


VLAN Configuration

- VLAN Settings: Click this checkbox to enable VLAN support.
- VLAN ID: Enter the ID for VLAN configuration. The range is from 1 to 4095.
- VLAN Priority: Enter the priority for VLAN configuration. The value range is from 1 to 7, with 7 being the highest priority level.

Click the Save button to save any changes, or click the Reset button to reset all modified fields to their original values.

2.5.10 PAM Order

Use this feature to configure the PAM order for user authentication. Click *PAM Order* in the Configuration submenu to display the page below.



1. PAM Module: The available PAM supported in the BMC are listed here.
2. Move Up: Select a PAM module and click this arrow button to move the module up one level.
3. Move Down: Select a PAM module and click this arrow button to move the module down one level.
4. Save: Click this button to save changes.
5. Reset: Click this button to reset any changes to the original order.

2.5.11 RADIUS

Use this feature to configure RADIUS settings for user authentication. Click *RADIUS* in the Configuration submenu to display the page below.



1. RADIUS Authentication: Click the checkbox to enable authentication and activate the fields below.
2. Port: Enter the RADIUS port number. The default port is 1812.
3. Time Out: Enter the amount of time to elapse before time out occurs. The range is from 3 to 300 seconds.
4. Server Address: Enter the IP address of the RADIUS server.
5. Secret: Enter the RADIUS server authentication secret. A maximum of 31 characters (and no white space) is allowed. The secret must be at least 4 characters long.
6. Save: Click this button to save any changes.
7. Reset: Click this button to reset any changes to the original values.

2.5.12 Remote Session

Use this feature to modify virtual media settings for redirection sessions. Click *Remote Session* in the Configuration submenu to display the page below.

Host Identification
Server: BMC00289007E7BD (172.31.8.255)
User: ADMIN (Administrator)

Summary FRU Information Server Health Configuration Remote Control Maintenance Miscellaneous REFRESH Logout HELP

Configure Remote Session

The following options are to enable or disable encryption on KVM or Media data for the next redirection session.

1 KVM Encryption Enable

2 Media Encryption Enable

3 Virtual Media Attach Mode Attach

4 Save 5 Reset

1. KVM Encryption: Use this checkbox to enable or disable encryption on KVM data for the next redirection session.
2. Media Encryption: Use this checkbox to enable or disable encryption on Media data for the next redirection session.
3. Virtual Media Attach Mode: Click the pull-down menu to display virtual media attach modes.
 - Attach: Select this mode to attach Virtual Media to the server immediately upon bootup. A virtual device will always be seen in the system BIOS even when it is not active.
 - Auto Attach: Select this mode to only attach Virtual Media to the server when a virtual media session is started. Virtual devices will only be shown in the operating systems and BIOS when a device or an ISO image is connected through the virtual media wizard.
4. Save: Click this button to save any changes made. If any remote sessions are currently active, clicking Save will automatically close the remote redirection session.
5. Reset: Click this button to reset any changes to the original settings.


2.5.13 Services

Use this feature to view or modify basic services running in the BMC. Click *Services* in the Configuration submenu to display a list of available services and their settings, as shown in the image below.



Modifying a Service

To modify a service, select a slot from the list and click the Modify button (or double-click the slot) to open the configuration window shown below.



1. Service Name: The service name of the selected slot is displayed. This field is read only.
2. Current State: Click this checkbox to change the state of the service to active or inactive. When checked, the service is active and the fields below are enabled.
3. Interfaces: Displays the interface in which the service is running. Select any of the other available interfaces from the drop-down list.
4. Nonsecure Port: Enter the non-secure port number for the service. The default non-secure port of each service is listed below:
 - Web: Port 80
 - KVM: Port 7578

- CD Media: Port 5120
- FD Media: Port 5122
- HD Media: Port 5123
- Telnet: Port 23



Note: SSH service does not support non-secure port.

5. **Secure Port:** Enter the secure port number for the service. The default secure port of each service is listed below:

- Web: Port 443
- KVM: Port 7582
- CD Media: Port 5124
- FD Media: Port 5126
- HD Media: Port 5127
- SSH: Port 22



Note: Telnet service does not support secure port.

6. **Timeout:** Displays the session timeout value. A timeout value can only be configured for Web, Telnet, and SSH services. The timeout value range is:

- Web: 300 to 1800 seconds
- SSH and Telnet: 30 to 1800 seconds (Telnet and SSH have a shared timeout value. If a value is configured for one, it is applied to the other.)

7. **Maximum Sessions:** A read-only field that displays the maximum amount of allowed sessions.

8. **Modify:** Click this button to save any changes and return to the Services list. If a session is already opened for a service, the service will be restarted.

9. **Cancel:** Click this button to abort any changes and return to the Services list.

2.5.14 SMTP

Use this feature to configure Simple Mail Transfer Protocol (SMTP) settings for email transmission. Click *SMTP* in the Configuration submenu to display the page below.

The screenshot shows the SUPERMICR X9 SMM IPMI Configuration page. At the top, there is a navigation menu with options: Summary, FRU Information, Server Health, Configuration (selected), Remote Control, Maintenance, and Miscellaneous. Below the menu, the page title is "SMTP Settings". The main content area is titled "Manage SMTP settings of the device." and contains the following fields:

- Sender Address:** A text input field.
- Machine Name:** A text input field.
- Primary SMTP Server:**
 - Server Address:** A text input field.
 - SMTP Server requires Authentication
 - User Name:** A text input field.
 - Password:** A text input field.
- Secondary SMTP Server:**
 - Server Address:** A text input field.
 - SMTP Server requires Authentication
 - User Name:** A text input field.
 - Password:** A text input field.

At the bottom right of the form, there are two buttons: "Save" and "Reset".

The available SMTP settings are described below:

- **Sender Address:** Enter a valid sender address on the SMTP server.
- **Machine Name:** Enter the machine name of the SMTP server. Up to 15 alphanumeric characters are allowed. Spaces and special characters are not allowed.

Primary SMTP Server

- **Server Address:** Enter the SMTP server IP address (field is mandatory). Both IPv4 and IPv6 address formats are supported.
- **SMTP Server requires Authentication:** Click this checkbox to enable SMTP authentication. Supported authentication types include CRAM-MD5, LOGIN, and PLAIN. If none of these authentication types are supported by the SMTP server, an error message will be generated.
- **User Name:** Enter the username that will access SMTP accounts. The value range is from 4 to 64 alpha-numeric characters. The username must start with a letter and cannot contain the following special characters: comma (,), colon (:), semicolon (;), space (), or backslash (\).
- **Password:** Enter the password that will be used for the SMTP user account. The value range is from 4 to 64 characters, with no white spaces allowed.
- **Secondary SMTP Server:** This optional field lists the secondary SMTP server. The secondary SMTP server will be used if the primary server is unavailable.

Click Save to save changes, or click Reset to reset fields to the original settings.

2.5.15 SSL

Use this feature to configure Secure Socket Layer (SSL) protocol settings for secure transactions. Click **SSL** in the Configuration submenu to display the page below.

SUPERMICR® Host Identification: Server: BMC062600R1TD (172.31.8.56) User: ADMIN (Administrator)

Summary | FRU Information | Server Health | **Configuration** | Remote Control | Maintenance | Miscellaneous | [Refresh](#) | [Print](#) | [Logout](#) | [HELP](#)

SSL Certificate Configuration

This page is used to configure SSL certificate into the BMC. Using this, the device can be accessed in a secured mode. Upload SSL option is used to upload the certificate and private key file into the BMC. Generate SSL option is used to generate the SSL certificate based on configuration details. View SSL option is used to view the uploaded SSL certificate in readable format.

1 Upload SSL | **2 Generate SSL** | **3 View SSL**

Current Certificate	Thu Jan 1 00:00:00 1970	<input type="button" value="Browse..."/>
New Certificate		<input type="button" value="Browse..."/>
Current Privacy Key	Thu Jan 1 00:00:00 1970	<input type="button" value="Browse..."/>
New Privacy Key		<input type="button" value="Browse..."/>

The SSL Certificate Configuration page is divided into the following three sections:

1. **Upload SSL:** Use this tab to upload a certificate and private key file into the BMC. See section 2.5.15.a
2. **Generate SSL:** Use this tab to generate the SSL certificate based on configuration details. See section 2.5.15.b
3. **View SSL:** Use this tab to view an uploaded SSL certificate. See section 2.5.15.c.

2.5.15.a SSL - Upload SSL

Click the Upload SSL tab in the SSL Certificate Configuration page to display the configuration information shown below.

1. Current Certificate: Displays current certificate information (read-only).
2. New Certificate: Click the Browse button to the right of this field to select a certificate file (the file should have a .pem extension).
3. Current Privacy Key: Displays current privacy key information (read-only).
4. New Privacy Key: Click the Browse button to the right of this field to select a privacy key file (the file should have a .pem extension).
5. Upload: Click this button to upload any new certificate or privacy key files into the BMC.

 **Note:** Once the files are successfully uploaded, HTTPs service will be restarted to use the new certificate.

2.5.15.b SSL - Generate SSL

Click the Generate SSL tab in the SSL Certificate Configuration page to display the configuration information shown below.


The screenshot shows the 'SSL Certificate Configuration' page in the SUPERMICR interface. The page has a navigation bar with 'Configuration' selected. Below the navigation bar, there are three tabs: 'Upload SSL', 'Generate SSL', and 'View SSL'. The 'Generate SSL' tab is active. The form contains the following fields:

- 1 Common Name(CN)
- 2 Organization(O)
- 3 Organization Unit(OU)
- 4 City or Locality(L)
- 5 State or Province(ST)
- 6 Country(C)
- 7 Email Address
- 8 Valid for (days)
- 9 Key Length (512 bits)
- 10 Generate button

1. Common Name(CN): Enter the common name (64 characters maximum) for the generated certificate. The '#' and '\$' special characters are not allowed.
2. Organization(O): Enter the organization name (64 characters maximum) for the generated certificate. The '#' and '\$' special characters are not allowed.
3. Organization Unit(OU): Enter the overall organization section unit name (64 characters maximum) for the generated certificate. The '#' and '\$' special characters are not allowed.
4. City or Locality(L): Enter the city or locality of the organization (required). A maximum of 64 characters is allowed ('#' and '\$' characters are not allowed).
5. State or Province(ST): Enter the state/province of the organization (required). 64 characters maximum is allowed ('#' and '\$' characters are not allowed).
6. Country(C): Enter the two-character country code of the organization (required). Only two characters (no special characters) are allowed.
7. Email Address: Enter the email address of the organization (required).
8. Valid for: Enter the number of days (from 1 to 3650) the certificate is valid.
9. Key Length: Use the drop-down list to select 512 bits or 1024 bits.
10. Generate: Click this button to generate the new certificate. Once it is successfully generated, HTTPs service will be restarted to use the new certificate. Your internet browser will now indicate **https://<your system IP address>**.

2.5.15.c SSL - View SSL

Click the View SSL tab in the SSL Certificate Configuration page to view a list of SSL information similar to the image below.



The SSL information is divided into the following four sections:

- **Basic Information:** This section lists basic information about the SSL certificate.
- **Issued From:** This section lists information about the certificate issuer.
- **Validity Information:** This section lists information about the certificate validity period.
- **Issued To:** This section lists information about the certificate owner.

2.5.16 System and Audit Log

Use this feature to change settings for event and audit logs. Click *System and Audit Log* in the Configuration submenu to display the page below.

The screenshot shows the 'System & Audit Logs' configuration page. At the top, there is a 'Host Identification' box showing 'Server: SMC002900FE7BD | 172.31.8.288 | User: ADMIN (Administrator)'. Below this is a navigation bar with tabs for 'Summary', 'FRU Information', 'Server Health', 'Configuration', 'Remote Control', 'Maintenance', and 'Miscellaneous'. The 'Configuration' tab is active, and the 'System & Audit Logs' sub-tab is selected. The page displays a table of logs with the following columns: 'Event ID', 'Time Stamp', 'IP Address', and 'Description'. The table contains 7 rows of log entries. On the left side, there are two checkboxes: 'System Log' (checked) and 'Audit Log' (unchecked). Below these are several input fields for configuration: 'Start by: Warning', 'UTC Offset: (GMT+1:0)', and a filter 'This filter: 08 event entries'. On the right side, there are two buttons: 'Save' and 'Reset'. The buttons are circled with red numbers 7 and 8 respectively. The table entries include error messages such as 'Unable to send a IPMI Response' and 'Sensor reading number format is non-analog'.

Event ID	Time Stamp	IP Address	Description
1	Feb 2 11:54:26	SMC002900FE7BD	IPMI: 0113:VIAWRANQ@IPMIBrc:c:01@IPMIBrc: c: Unable to send a IPMI Response
2	Feb 2 11:53:29	SMC002900FE7BD	weblog: 1019:VIAWRANQ@sensor_helpers.c:392@Sensor reading number format is non-analog!
3	Feb 2 11:53:29	SMC002900FE7BD	last message repeated 5 times
4	Feb 2 11:57:23	SMC002900FE7BD	weblog: 1019:VIAWRANQ@sensor_helpers.c:392@Sensor reading number format is non-analog!
5	Feb 2 11:58:28	SMC002900FE7BD	last message repeated 12 times
6	Feb 2 11:58:28	SMC002900FE7BD	last message repeated 5 times
7	Feb 2 11:58:30	SMC002900FE7BD	IPMI: 0113:VIAWRANQ@IPMIBrc:c:55@IPMIBrc: c: Error sending IPMI packet to Slave Dr15

The available system and audit settings are described below:

1. **System Log:** Click the Enable checkbox to allow system logs and to enable configuration for the following fields.
2. **Log Type:** Select between preserving system logs in a local or remote log. If Local Log is selected, the log file will be stored at `/var/log/`.
3. **File Size:** If Local Log is selected (above), enter the file size of the log file. The size range is from 3 to 65535 bytes.
4. **Rotate Count:** If log information exceeds the preset file size (above), old log information will automatically be transferred to a back-up files based on the rotate count number. Enter a rotate count number ranging from 0 to 255.



Note: If the rotate count number is 0, old log information will be cleared permanently.

5. **Server Address:** If the Log Type is set to Remote Log, enter the remote server address where logs will be stored. Both IPv4 and FQDN (Fully Qualified Domain Name) address formats are supported.
6. **Audit Log:** Click the Enable checkbox to enable audit logs.
7. **Save:** Click this button to save any changes
8. **Reset:** Click this button to reset any modifications to the original settings.

2.5.17 Users

Use this feature to add and modify user settings. Click *Users* in the Configuration submenu to display a list of the current available users, similar to the page below.

User Management

The list below shows the current list of available users. To delete or modify a user, select their name in the list and press "Delete User" or "Modify User". To add a new user, select an unconfigured slot and press "Add User".

User ID	Username	User Access	Network Privilege	Email ID
1	anonymous	Disabled	Administrator	--
2	ADMIN	Enabled	Administrator	--
3	--	--	--	--
4	--	--	--	--
5	--	--	--	--
6	--	--	--	--
7	--	--	--	--
8	--	--	--	--
9	--	--	--	--
10	--	--	--	--

Buttons: Add User, Modify User, Delete User

The User Management page contains the following items:

1. Number of configured users: Displays the current number of the users that are set up for the network. A maximum of 10 user profiles can be created.
2. User ID: Displays the ID number of the user.
3. Username: Displays the name of the user.
4. User Access: Displays the user access privilege (enabled or disabled).
5. Network Privileges: Displays the network access privilege for the user.



Note: You must have at least Operator privileges to view the User Management page. You must have Administrator privileges to modify or add a user.

6. Email ID: Displays the email address configured for the user.
7. Add User: Click this button to add a new user to the network (see section 2.5.17.a).
8. Modify User: Click this button to modify the information or the status of a user (see section 2.5.17.a).
9. Delete User: Click this button to delete a user from the network.

2.5.17.a Users - Adding and Modifying Users

To add a user, select an empty slot and click the Add User button at the bottom of the User Management page. To modify a user, select a configured slot and click the Modify User button. Whether adding or modifying a user, virtually the same window is displayed, similar to the image below.

A description for each of the fields is provided below:

1. Username: Enter the name of the user. The case-sensitive name must be from 4 to 16 characters and start with a letter character. The following special characters are not allowed: comma, period, colon, semicolon, space, slash, backslash, left parenthesis, right parenthesis.
2. Password Size: Select the desired maximum password size of 16 or 20 bytes.
3. Password, Confirm Password: Enter and confirm the password. No white space is allowed and the password must be at least eight (8) characters long, but not exceed 20 characters.
4. User Access: Click the checkbox to enable network access for the user.
5. Network privilege: Select the network privilege level for the user. The available levels are Administrator, Operator, User, OEM Proprietary, and No Access.
6. Email ID: Enter the email address for the user.



Note: The SMTP server must be configured to send an email. See section 2.5.14.

7. Email Format: Select the type of email format to use. There are two types:
 - AMI-Format: Using this format, the email alert is automatically generated. The email subject will show as "Alert from (your Hostname)" and the mail content will display sensor information, such as sensor type and description.
 - Fixed-Subject Format: Using this format, you manually enter the subject and message for the email alert and the email message will display according to the user's setting.
8. Uploaded SSH Key: This read-only field displays only when modifying a user.
9. New SSH Key: Use the Browse button to locate and upload the SSH Key (the file should have a .pub extension).
10. Modify: Click this button to save changes and return to the Users list.
11. Cancel: Click this button to abort changes and return to the Users list.

2.5.18 Virtual Media

Use this feature to change settings for virtual media redirection. Click *Virtual Media* in the Configuration submenu to display the page below.

The screenshot shows the SUPERMICR web interface. At the top, there is a navigation bar with the following items: Summary, FRU Information, Server Health, Configuration (highlighted), Remote Control, Maintenance, and Miscellaneous. On the right side of the navigation bar, there are links for Refresh, Data, and Logout, along with a HELP icon. Below the navigation bar, the page title is "Virtual Media Devices". A sub-header reads: "The following option will allow to configure virtual media devices:". Below this, there are three configuration fields, each with a dropdown menu set to "1":
Floppy devices: 1
CD/DVD devices: 1
Harddisk devices: 1
At the bottom right of the configuration area, there are two buttons: "Save" and "Reset".


There are three fields that can be configured:

- Floppy Devices
- CD/DVD Devices
- Harddisk Devices

For each of these fields, select the number of devices that virtual media redirection will support. Click the Save button to save any changes, or click the Reset button to reset any changes back to the original settings.

2.6 Remote Control

This section allows the user to carry out activities and perform operations on a remote server via remote access. Click *Remote Control* in the main menu to display the submenu items, as shown below.



The Remote Control submenu allows you to perform the following remote actions:

- **Console Redirection:** Launches the redirection console for remote server management
- **Serial over LAN:** Launches the serial over LAN (SOL) for remote server management
- **Server Power Control:** Provides power control capabilities, such as power on, power off, and reset.


2.6.1 Remote Console

This feature allows you to perform various activities on the server remotely. Click *Remote Console* in the Remote Control submenu to display the page below.




Follow the instructions below to launch the remote console.


1. **Launch Console:** Click the button to launch the remote console via the Java script. Alternatively, you can click 'Summary' in the main menu bar, then click the launch button in the Remote Control section.
2. **Security Message:** Upon launching the remote console, a window will display with a security message. Click on the message and select Download File, as indicated below.



3. **Security Warning:** A security warning will appear (as shown below), indicating that the web site's certificate cannot be verified. Click the checkbox "Always trust content from this publisher" to eliminate further security warnings, then click Yes to proceed.



- The remote console will continue launching until the screen of the client system is displayed as shown below.




At the top of the remote console viewer (shown above) is a Menu bar with a row of quick button items beneath. The Menu bar items are described in sections 2.6.1.a through 2.6.1.i. The quick button functions are described in the table below.

Quick Button	Description
	Plays Console redirection (when paused)
	Pauses Console redirection
	Scales Console redirection to full screen
	Opens a virtual media for the device if connected
	Shows or hides the mouse cursor on client system
	Shows or hides the soft keyboard
	Records video (see section 2.6.1.g)
	Lists the HotKeys
	Zooms client screen in or out
	Indicates server power status (red=off, green=on) and can be used to power the server on or off

2.6.1.a Console Redirection - Video

Use this item to configure video settings for your remote console. Click *Video* in the Menu bar to display the video options as shown below.




The options in the Video submenu are described below.

- Pause Redirection: Freezes the screen.
- Resume Redirection: Re-activates a frozen screen.
- Refresh Video: Refreshes the display.
- Full Screen: Expands the display to full screen mode.
- Exit: Closes the Remote Console window.

2.6.1.b Console Redirection - Keyboard

Use this item to emulate keyboard strokes on the remote console. Click *Keyboard* in the Menu bar to display the remote console keyboard options as shown below.



The options in the Keyboard submenu described below.


- Hold Right Ctrl Key: Check this to emulate the right Ctrl key when it is pressed.
- Hold Right Alt Key: Check this to emulate the right alt key when it is pressed.
- Hold Left Ctrl Key: Check this to emulate the left Ctrl key when it is pressed.
- Hold Left Alt Key: Check this to emulate the left alt key when it is pressed.
- Left Windows Key: Scroll over this to display the following submenu items:
 - Hold down: Check this to emulate the left window key when pressed.
 - Press and Release: Click this to press and release the left window key.
- Right Windows Key: Scroll over this item to display the following submenu items:
 - Hold down: Check this to emulate the right window key when pressed.
 - Press and Release: Click this to press and release the right window key.
- Ctrl+Alt+Del: Click this to emulate pressing Ctrl+Alt+Del simultaneously.
- Context Menu: Click this to emulate the context menu key.



Note: To activate the soft keyboard, click the keyboard icon  in the quick button row beneath the Menu bar.

2.6.1.c Remote Console - Mouse

Use this feature to configure the mouse settings for the remote console. Click *Mouse* in the Menu bar to display the options as shown below.



The options in the Mouse submenu are described below.

- Show Cursor: Click this item to display the cursor on the screen.
- Mouse Calibration: Check this box to calibrate the mouse threshold settings. The local mouse color will appear in RED and the remote cursor (in the remote console window) will appear in white. Both mouse cursors are initially synchronized. Use the (+) or the (-) keys to adjust the threshold settings until the cursors fall out of synch. Once the desired level of synchronization is achieved, press Alt+T simultaneously to lock the threshold value.



Note: Mouse Calibration is enabled only when the mouse mode is set to Relative (see below).


- Mouse Mode: (Administrator only) Use this feature to configure how mouse emulation is handled from the local window to the remote screen. The two options are:
 - Absolute Mode: Check this radio button to use the Absolute mode for the Windows OS. This will send the absolute position of the local mouse to the server.
 - Relative Mode: Check this radio button to use the Relative mode for the Linux/Unix OS. This will send the relative calculated mouse position displacement to the server.



Note: IPMI is an OS-independent platform, and KVM support is an added feature for IPMI. For your mouse to function properly, please configure the Mouse Mode settings (above) according to the remote server's OS type.

2.6.1.d Remote Console - Options

Use this feature to configure bandwidth, zoom, and keyboard options. Click *Options* in the Menu bar to display the items shown below.




The available options are described below:


- **Bandwidth:** Provides keyboard bandwidth adjustment options. Select one of the following:
 - Auto Detect
 - 256 Kbps
 - 512 Kbps
 - 1Mbps
 - 10Mbps
- **Keyboard/Mouse Encryption:** Allows encryption of keyboard input and mouse movements sent between the local and remote system.
- **Zoom:** Select between Zoom In and Zoom Out to deviate from the default zoom of 100%.
 - **Zoom In:** Increases screen size up to 150% by 10% increments.
 - **Zoom Out:** Decreases screen size down to 50% by 10% increments.

2.6.1.e Remote Console - Media

Use this feature to configure media virtualization for the remote console. Click *Media* in the Menu bar to display the Virtual Media option shown below.



Click *Virtual Media Wizard* to launch the window shown below to configure Virtual Media settings.



1. Floppy/USB Key Media: This section allows the user to start or stop the redirection of a floppy drive or floppy image (such as a .img file). Select one of the available options or click the Browse button to select the location of the floppy image.
2. Connect Floppy: After selecting the Floppy Media for your remote console, click the Connect Floppy button to connect to the remote console via the drive chosen.

3. **CD/DVD Media:** This section allows the user to start or stop the redirection of a CD/DVD drive or CD image (such as a .iso file). Select one of the available options or click the Browse button to select the location of the CD/DVD image.
4. **Connect CD/DVD:** After selecting the CD/DVD Media for your remote console, click the Connect CD/DVD button to connect to the remote console via the drive chosen.
5. **Hard disk/USB Key Media:** This section allows the user to start or stop the redirection of a Hard disk/USB Key drive or image (such as a .img file). Select one of the available options or click the Browse button to select the location of the Hard disk/USB Key image.
6. **Connect Hard disk/USB Key:** After selecting the Hard disk/USB Key Media for your remote console, click the Connect Hard disk/USB Key button to connect to the remote console via the drive chosen.
7. **Status:** This window displays the status of the target drive of the remote console.



Notes: For Windows client: If a logical drive (on the physical drive) is dismounted, the logical device will be redirected with Read permission only.


For MAC client: Only USB Hard disk redirection is supported.

For Linux client: Write mode is not supported for fixed hard drive redirection. Only Read mode is supported.

For USB key image: Supported formats are FAT16, FAT32, and NTFS.

2.6.1.f Remote Console - Keyboard Layout

Use this feature to configure keyboard layout settings for the remote console. Click *Keyboard Layout* in the Menu bar to display the options as shown below.



The options in the Keyboard Layout submenu are described below.

- **Auto Detect:** Check this to automatically detect the keyboard layout. The automatically supported languages are English (US), French (France), Spanish (Spain), German (Germany), and Japanese (Japan).

 **Note:** With the exception of English, if the client and host languages are the same, select the Auto Detect option to avoid keyboard (typing) errors.


- **SoftKeyboard:** Scroll over this item to display a list of languages for the soft keyboard layout. Select a language from the list to display the soft keyboard, similar to the image below.

 **Note:** The soft keyboard option is available only for the JViewer application.



2.6.1.g Remote Console - VideoRecord

Use this feature to perform video recording actions for the remote console. Click *VideoRecord* in the Menu bar to display the options as shown below.




The options in the Keyboard Layout submenu are described below.


- Start Record: Click this to start recording the remote console display.
- Stop Record: Click this to stop recording.

 **Note:** Start Record and Stop Record are initially not selectable. To enable recording, the settings must first be configured (see below).


- Settings: Click this item to configure video settings. Follow the instructions below to enable video recording.
1. Click Settings (see above) to open the Video Record window.
 2. In the Video Record window (below), enter the amount of time (in seconds) for the recording.
 3. Click the Browse button to open a directory window and select a location for the video to be saved.




- In the Directory window, select a location and click the Choose Directory button. This will return you to the Video Record window.



- In the Video Record window, click OK to save the entries and return to the Console Redirection screen.




- Click VideoRecord in the redirection window. The Start Record option is now enabled.



2.6.1.h Remote Console - Power


Use this feature to perform power functions using the remote console. Click *Power* in the Menu bar to display the options as shown below.



The options in the Power submenu are described below.

- Reset Server: Reboots the system without powering off.
- Immediate Shutdown: Immediately powers off the server.
- Orderly Shutdown: Powers off the server after OS shutdown functions have completed.
- Power On Server: Powers on the server.
- Power Cycle Server: Powers off the server, then reboots the system.

2.6.1.i Remote Console - Active Users and Help




The Active Users and Help menu (indicated above) are described below.

- **Active Users:** Click this to display all active users (and their system IP address) that are connected to the host system.
- **Help:** Click this to display the JViewer version and copyright information.


2.6.2 Serial Over LAN

This feature allows you to launch the remote console by using Serial over LAN (SOL). Click *Serial over LAN* in the Remote Control submenu to display the page below.



Follow the instructions below to launch SOL.

1. Click the SOL Console button (shown above) to launch the remote console. The IPMI SOL window displays as shown below.




2. A security warning will appear (shown below), indicating that the application's digital signature cannot be verified. Mark the checkbox "Always trust content from this publisher" to eliminate further security warnings.
3. Click Run to continue launching SOL.



- The SOL console redirection will display as shown below. Select a Baud Rate from the drop-down list to configure the SOL transfer rate.

 **Note:** Make sure that the baud rate selected matches the baud rate set in the BIOS.



- Click the Start button to start the SOL session or click the Stop button to abort the session.

2.6.3 Server Power Control

Use this feature remotely perform power functions for the host server. Click *Server Power Control* to display the page below.




Select a power control function then click Perform Action (lower right-side of page) to execute. The power control options are described below.

- **Reset Server:** Reboots the system without powering off.
- **Power Off Server - Immediate:** Immediately powers off the server.
- **Power Off Server - Orderly Shutdown:** Powers off the server after OS shutdown functions have completed.
- **Power On Server:** Powers on the server.
- **Power Cycle Server:** Powers off the server, then reboots the system.

2.7 Maintenance

This menu allows the user to manage various maintenance tasks on the device. Click *Maintenance* in the main menu to display the submenu contents, as shown below.




The Maintenance submenu contains the following items:


- BIOS Update
- Firmware Update
- Preserve Configuration
- Restore Factory Defaults
- System Administrator

2.7.1 BIOS Update

This feature allows the user to perform a BIOS update. Click *BIOS Upgrade* in the Maintenance submenu to display the page shown below.



1. To begin the BIOS update process, click the Enter Update Mode button (see above). A message will display.
2. A message displays (see below) indicating that you will not be able to perform any other tasks until the upgrade is complete. Click OK to continue. Otherwise, click Cancel to return to the BIOS Update page.




3. Follow the instructions that are subsequently presented on screen to complete the BIOS update.

 **Note:** Once you have entered Update Mode, the device will be reset even if you cancel.

 **Warning:** Take precautionary measures to prevent power interruption from happening during firmware updates to avoid possible device failure. Do not cancel the BIOS Upload process after clicking the *Upload* button.

2.7.2 Maintenance - Firmware Update

This feature allows the user to perform a firmware update. Click *Firmware Update* in the Maintenance submenu to display the page shown below.



Host Identification
Server: BMC0205PM0E71D (172.31.8.246)
User: ADMIN (Administrator)

Summary FRI Information Server Health Configuration Remote Control Maintenance Miscellaneous Refresh Print Logon HELP

Firmware Update

Upgrade firmware of the device. Press 'Enter Update Mode' to put the device in update mode.

WARNING: Please note that after entering update mode widgets, other web pages and services will not work. All open widgets will be closed automatically. If upgrade process is cancelled in the middle of the wizard, the device will reset.

1 Preserve all Configuration. This will preserve all the configurations during firmware update. In spite of the individual items to be preserved/overwritten in the below list.

This section lists the configuration items, that will be preserved during restore factory default configuration. Click 'Enter Preserve Configuration' to modify the preserve configuration items.

#	Preserve Configuration Item	Preserve Status
1	SSH	Overwrite
2	SEL	Overwrite
3	IPMI	Overwrite
4	Network	Overwrite
5	NTP	Overwrite
6	SSH	Overwrite
7	KMII	Overwrite
8	Authentication	Overwrite

3 4
Enter Preserve Configuration Enter Update Mode

1. Click the checkbox to preserve all configuration items listed on the page.

 **Note:** If this box is left unchecked, all configuration items listed that are not set to "Preserve" will be overwritten with factory default settings during firmware upgrade.

2. A list of configuration items is displayed here. These items can be preserved or overwritten during the firmware upgrade process. To preserve individual items, click the Enter Preserve Configuration button and follow the instructions in section 2.7.3 (next page). To preserve all items, regardless of the Preserve Configuration settings, click the checkbox shown at #1 above.
3. Click the Enter Preserve Configuration button to select individual items to preserve during the firmware update. See section 2.7.2.a.
4. Click the *Enter Update Mode* button to proceed. Follow the instructions that are subsequently presented on screen to complete the firmware update.

 **Note:** Once you have entered Update Mode, the device will be reset even if you cancel.

 **Warning:** Take precautionary measures to prevent power interruption from happening during firmware updates to avoid possible device failure. Do not cancel the Firmware Upload process after clicking the *Upload* button.

2.7.3 Preserve Configuration

Use this feature to preserve individual configuration items from being overwritten when performing a firmware update or when restoring factory defaults. Click *Preserve Configuration* from the Maintenance submenu to display a page similar to the image below.

For information on changing the preserve configuration settings, see section 2.7.4.



1. Click the checkbox under Preserve Status to preserve an individual configuration item.

Note 1: If you are using the Static IP mode, it is recommended to preserve the Network configuration, otherwise the update process will reset the network settings to DHCP (Dynamic Host Configuration Protocol) mode.

Note 2: Any configuration item left unchecked will be overwritten with factory default settings during firmware update.

2. Check All: Click this button to preserve all configuration items in the list.
3. Uncheck All: Click this button to overwrite all configuration items in the list.
4. Save: Click this button to save the settings and return to the Firmware Update page.
5. Reset: Click this button to undo any changes that were made since entering the Preserve Configuration page.

2.7.4 Restore Factory Defaults

Use this feature to restore all settings of the device to the default configuration. Click *Restore Factory Defaults* from the Maintenance submenu to display the page below.

The screenshot shows the SUPERMICR BMC/IPMI interface. At the top, there is a navigation menu with options: Summary, FRU Information, Server Health, Configuration, Remote Control, Maintenance, and Miscellaneous. The 'Maintenance' option is selected. Below the menu, the page title is 'Restore Factory Defaults'. A warning message states: 'WARNING: Please note that after entering into restore factory defaults, widgets, other web pages and services will not work. All open widgets will be closed automatically. The device will reset and reboot within few minutes.' Below the warning, there is a table with two columns: 'Preserve Configuration Item' and 'Preserve Status'. The table content is '1 DATA NOT AVAILABLE'. At the bottom of the page, there are two buttons: 'Enter Preserve Configuration' (circled in red and numbered 2) and 'Restore Factory Defaults' (circled in red and numbered 3).

1. Preserve Configuration Item list: If any configuration items are marked as "Preserve," those items will be listed in this area. If no configuration items are marked as "Preserve," this area will indicate "Data Not Available."
2. Enter Preserve Configuration: Click this button to select configuration items to preserve. See section 2.7.3 (previous page).
3. Restore Factory Defaults: Click this button to restore defaults to the factory settings.

 **Note:** During the factory restore process, the device will take a few minutes to automatically reset and reboot.

2.7.5 Restore System Administrator

Use this feature to modify system administrator settings. Click *System Administrator* from the Maintenance submenu to display the page below.

Below is a description of all the available system administrator settings.

1. Username: The username of the administrator is displayed (read-only).
2. User Access: Mark this checkbox to enable user access for the administrator.
3. Change Password: Mark this checkbox to change the administrator password.
4. Password, Confirm Password: If the Change Password checkbox is marked, enter the new password into these fields.




Note: The new password must be from 8 to 16 characters long, with no white space.


5. Save: Click this button to save any changes.
6. Reset: Click this button to reset any changes to the original settings.

2.8 Miscellaneous

This feature allows the user to perform the miscellaneous activities displayed below.



1. **Post Snooping:** Click this item to display the above image and query the POST (Power On Self-Test) Snooping code. Click the Refresh button to get the current post snooping code.
2. **Power Management:** Click this item to display the below image.




- **Current Power Consumption:** Displays (read-only) the current total power consumption for the server. Click the Refresh button to display updated data.

 **Note:** If the power supply does not support this feature, the data in this field will show as Not Available.

- **Power Capping:** Click the checkbox to enable power capping, then enter the maximum number of watts the system will be allowed to consume. Click Save to save changes.

3. **UID:** Click this item to enable or disable UID (Unit Identification) support, as shown in the image below.



Click one of the options to enable or disable UID, then click the Save button. A message will display asking if you're sure you want to change the settings. Select OK to continue, otherwise select cancel to return to the UID setting page.

Notes

Appendix A

Flash Tools

A-1 Overview

This section provides instructions on how to use the Flash Tools. The Flash Tools allow the user to use Command_Line (CL) utility programs to upgrade or update firmware via different channels such as KCS, USB and LAN connections. This section will focus on the following tools:

- RWinFlash (Windows Flash)
- RLinFlash (Linux Flash)
- RKCSFlash (Keyboard Controller Style Flash)

RWinFlash and RLinFlash allow the user to flash the BMC in a Windows (RWinFlash) or a Linux (RLinFlash) environment via network or USB connections. You can choose to use network connections or USB connections to flash the BMC based on how you use the flash tools.

RKCSFlash is used to flash the firmware in the DOS environment via the KCS (Keyboard Controller Style) interface.

A-2 Flashing the BMC Firmware in the DOS Environment

RKCSFlash is the tool used to flash the BMC firmware in DOS through the KCS interface. To flash the BMC, follow the instructions below:



Warning: Avoid any interruption during the firmware update process. Any interruption may result in device failure.

1. Copy RKCSFlash.exe into a bootable USB.
2. Run the RKCSFlash utility.

3. Use the settings as listed below.

- Format:

RKCSF`lsh` [OPTION] [FW_IMAGE_FILE]

[OPTIONS]

Options Commands	
-info	This option displays information regarding existing and current firmware.
-force-boot	Select this option to force the boot loader to be upgraded during full upgrade. The boot loader is "preserved" by default.
-preserve-config	This option preserves configuration modules during full upgrade.
-i	This option allows for interactive upgrade (only the required modules are upgraded).

[FW_IMAGE_FILE]

The firmware-image file name is [rom.ima].

Examples

- **Example 1**

/RKCSF`lsh` rom.ima

Description: This command starts flashing the new rom.ima to the firmware.

- **Example 2**

/RKCSF`lsh` -info rom.ima

Description: This command displays the details of both existing and new firmware.

- **Example 3**

/RKCSF`lsh` -force-boot rom.ima

Description: This command starts flashing the new rom.ima to the firmware using "FORCE BootLoader upgrade."

A-3 Flashing the BMC Firmware in the Windows Environment

RWinFlash is used to flash the BMC firmware in Windows through USB or Network connections. To flash the BMC in Windows, follow the instructions below.



Warning: Avoid any interruption during the firmware update process. Any interruption may result in device failure.

1. Open Command Prompt. Go to RWinFlash\Windows\path.
2. The following two files will be displayed:
 - RWinFlash.exe
 - LIBIPMI.dll
3. Run "RWinFlash.exe" in the command prompt.
4. Use the settings as listed below.
 - Format:

RWinFlash [OPTION] [MEDIUM] [FW_IMAGE_FILE]

[OPTIONS]

Options Commands	
-info	This option displays information regarding existing and new firmware.
-force-boot	Select this option to force the boot loader to be upgraded during full upgrade. The boot loader is "preserved" by default.
-preserve-config	This option preserves configuration modules during full upgrade.
-i	This option allows for interactive upgrade (only the required modules are upgraded).

[MEDIUM]

Medium Options	
-cd	Select this option to use USB connections.
-nw & ip	Select this option to use network with -ip (followed by the IP address).

[FW_IMAGE_FILE]

The firmware-image file name is [rom.ima].

Examples

Using Network as a Medium

- **Example 1**

```
RWinFlash -nw -ip 155.166.132.12 -info rom.ima
```

Description: This command displays the details of both existing and new firmware using the network connection with the ip address of 155.166.132.12.

- **Example 2**

```
RWinFlash -nw -ip 155.166.132.12 rom.ima
```

Description: This command starts flashing the new rom.ima to the firmware using the network connection with the IP address of 155.166.132.12.

- **Example 3**

```
RWinFlash -nw -ip 155.166.132.12 -force-boot rom.ima
```

Description: This command starts flashing the new rom.ima to the firmware with FORCE BootLoader Upgrade via the network connection using the IP address of 155.166.132.12.

Using USB as a Medium

To use USB as a medium, you must first mount USB as a virtual media (see Chapter 2, section 2.6.1.e, #5 and #6). Also, ensure that the Virtual Media Attach Mode is set to "Attach" (see Chapter 2, section 2.5.12, #3).

- **Example 1**

```
RWinFlash -cd -info rom.ima
```

Description: This command displays the details of both existing and new firmware using a USB connection.

- **Example 2**

```
RWinFlash -cd rom.ima
```

Description: This command starts flashing the new rom.ima to the firmware using a USB connection.

- Example 3

RWinFlash -cd -force-boot rom.ima

Description: This command starts flashing the new rom.ima to the firmware with FORCE BootLoader Upgrade using a USB connection.

```

C:\RWinFlash>RWin32Flash.exe -nv -ip 172.31.9.59 -info C:\RWinFlash\DRW6F1038.ima
YAFUFlash - Firmware Upgrade Utility (Version 2.9)
-----
(C)Copyright 2008, American Megatrends Inc.
Please enter login information:
User      : ADMIN
Password  : ****
Creating IPMI session via network with address 172.31.9.59...Done
-----
                          Firmware Details
-----
RomImage                   ExistingImage from Flash
-----
1.  ModuleName  Description  Version  ModuleName  Description  Version
2.  boot        BootLoader  0.1      boot        BootLoader  0.1
3.  pcie        pcie        0.1      pcie        pcie        0.1
4.  conf        ConfigParams 0.1      conf        ConfigParams 0.1
5.  bkupconf    bkupconf    1.2      bkupconf    bkupconf    1.2
6.  root        Root        0.1      root        Root        0.1
7.  osimage     Linux OS    0.6      osimage     Linux OS    0.6
8.  www         Web Pages  0.6      www         Web Pages  0.6
9.  rainier     rainier     1.10     rainier     rainier     1.10
-----
C:\RWinFlash>_

```

A-4 Flashing the BMC Firmware in the Linux Environment

RLinFish is used to flash the BMC firmware in the Linux environment using network or USB connections. To flash the BMC in Linux, follow the instructions below.

 **Warning:** Avoid any interruption during the firmware update process. Any interruption may result in device failure.

1. Open the Terminal. Go to RLinFish/Linux path.
2. The file libipmi.so.1 should be accessible to a Linux system. Usually when running an application, Linux will search for a file in dependent libraries in default locations, such as `usr/lib/lib` folders.
3. Copy `libipmi.so.1` to `/lib` or `/usr/local/lib`. Run `"ldconfig"`

or

Copy `libipmi.so.1` to a folder and issue the following command:

```
#LD_LIBRARY_PATH=<location_of_libipmi_so>/RLinFish
```



Note: You may have to create a link to `libipmi.so.1.0` (In-sf `libipmi.so.1.0` `libipmi.so.1`).

4. Use the settings as listed below.
 - Format:

```
/RLinFish [OPTION] [MEDIUM] [FW_IMAGE_FILE]
```

[OPTIONS]

Options Commands	
-info	This option displays information regarding existing and new firmware.
-force-boot	Select this option to force the boot loader to be upgraded during full upgrade. The boot loader is "preserved" by default.
-preserve-config	This option preserves configuration modules during full upgrade.
-i	This option allows for interactive upgrade (only the required modules are upgraded).

[MEDIUM]

Medium Options	
-cd	Select this option to use USB connections.
-nw & ip	Select this option to use network with <code>-ip</code> (followed by the IP address).

[FW_IMAGE_FILE]

The firmware-image file name is [rom.ima].

Examples

Using Network as a Medium

- **Example 1**

```
/RLinFlash -nw -ip 155.166.132.12 -info rom.ima
```

Description: This command displays the details of both existing and new firmware using the network connection with the IP address of 155.166.132.12.

- **Example 2**

```
/RLinFlash -nw -ip 155.166.132.12 rom.ima
```

Description: This command starts flashing the new rom.ima to the firmware using the network connection with the IP address of 155.166.132.12.

- **Example 3**

```
/RLinFlash -nw -ip 155.166.132.12 -force-boot rom.ima
```

Description: This command starts flashing the new rom.ima to the firmware with FORCE BootLoader Upgrade via the network connection using the IP address of 155.166.132.12.

Using USB as a Medium

To use USB as a medium, you must first mount USB as a virtual media (see Chapter 2, section 2.6.1.e, #5 and #6). Also, ensure that the Virtual Media Attach Mode is set to "Attach" (see Chapter 2, section 2.5.12, #3).

- **Example 1**

```
/RLinFlash -cd -info rom.ima
```

Description: This command displays the details of both existing and new firmware using a USB connection.

- **Example 2**

```
/RLinFlash -cd rom.ima
```

Description: This command starts flashing the new rom.ima to the firmware using a USB connection.

- **Example 3**

/RLinFlash -cd -force-boot rom.ima

Description: This command starts flashing the new rom.ima to the firmware with FORCE BootLoader Upgrade using a USB connection.

```
centoslive@livedvd:/home/centoslive/Desktop
File Edit View Search Terminal Help
[root@livedvd Desktop]# ./RLin64Flash -info -nw -ip 172.31.8.138 X9_1.10.3.ima
-----
YAFUFlash - Firmware Upgrade Utility (Version 2.9)
-----
(C)Copyright 2008, American Megalrends Inc.
Please enter login information:
User   : ADMIN
Password :

Creating IPMI session via network with address 172.31.8.138...Done
=====
                          Firmware Details
=====
```

RomImage		ExistingImage from Flash			
ModuleName	Description	Version	ModuleName	Description	Version
1. boot	BootLoader	0.1	boot	BootLoader	0.1
2. pcie		0.1	pcie		0.1
3. conf	ConfigParams	0.1	conf	ConfigParams	0.1
4. bkupcont		1.2	bkupcont		1.2
5. root	Root	0.1	root	Root	0.1
6. osimage	Linux OS	0.6	osimage	Linux OS	0.6
7. ww	Web Pages	0.6	ww	Web Pages	0.6
8. rainier		1.10	rainier		0.10

```
[root@livedvd Desktop]#
```

(Disclaimer Continued)

The products sold by Supermicro are not intended for and will not be used in life support systems, medical equipment, nuclear facilities or systems, aircraft, aircraft devices, aircraft/emergency communication devices or other critical systems whose failure to perform be reasonably expected to result in significant injury or loss of life or catastrophic property damage. Accordingly, Supermicro disclaims any and all liability, and should buyer use or sell such products for use in such ultra-hazardous applications, it does so entirely at its own risk. Furthermore, buyer agrees to fully indemnify, defend and hold Supermicro harmless for and against any and all claims, demands, actions, litigation, and proceedings of any kind arising out of or related to such ultra-hazardous use or sale.